

## Mousse

## Recipe Suggestion Palsgaard<sup>®</sup> Dessert 517



Product:	Frozen quark mousse.
Recipe:	%
	Palsgaard <sup>®</sup> Dessert 517       2.40         Skim milk quark, 18% TS       35.00         Yoghurt, 3.5% fat       10.00         Cream, 38% fat       20.00         Sugar       14.00         Skim milk       18.60         100.00
	100.00
	Add flavour as desired.
	Composition of solids:
	% Fat 8.00
	Fat6.00Milk-solids-non-fat9.60Sugar14.00Palsgaard <sup>®</sup> Dessert 5172.40
	Total solids 34.00
Procedure:	* Add Palsgaard <sup>®</sup> Dessert 517 to the mix while stirring
	<ul> <li>Adjust the pH-value to 4.2-4.4 by means of citric acid</li> </ul>
	* Continue mild agitation for approx. 30 min
	* Pasteurization: 70°C/1 min.
	* Homogenization: approx. 200 kp/cm <sup>2</sup>
	* Cool the mix to 23 - 25°C. At this temperature the mix is ready to enter the ice cream freezer. It is very important that the temperature of the mix stays above 20°C, as it will otherwise become too viscous to enter the freezer
	* Suggested overrun: 80 - 100%
	* Fill into container and transfer to freezer tunnel

Identification: MOUSSE FROZEN QUARK (00581701-EU-E-RS).doc

Palsgaard A/S – Palsgaardvej 10 – DK-7130 Juelsminde – Denmark – Phone: +45 76 82 76 82 – E-mail: Direct@palsgaard.dk – Fax: +45 76 82 76 83 The product is tested and recommended for use in mentioned application only. The information given is, to the best of our knowledge, reliable. However, no guarantees are given, not even in case of negligence on the part of Palsgaard A/S, and users of our products, are recommended and advised to conduct their own trials to determine whether our products are suitable for the user's specific purposes. In case of delivery of defective products the user is only entitled to order a new delivery. Palsgaard A/S assumes no guarantee against patent infringement, liabilities or risks involved from the use of this product or information given.



Identification: MOUSSE FROZEN QUARK (00581701-EU-E-RS).doc

Palsgaard A/S – Palsgaardvej 10 – DK-7130 Juelsminde – Denmark – Phone: +45 76 82 76 82 – E-mail: Direct@palsgaard.dk – Fax: +45 76 82 76 83 The product is tested and recommended for use in mentioned application only. The information given is, to the best of our knowledge, reliable. However, no guarantees are given, not even in case of negligence on the part of Palsgaard A/S, and users of our products, are recommended and advised to conduct their own trials to determine whether our products are suitable for the user's specific purposes. In case of delivery of defective products the user is only entitled to order a new delivery. Palsgaard A/S assumes no guarantee against patent infringement, liabilities or risks involved from the use of this product or information given.