

Ice Cream



Recipe Suggestion

Palsgaard® MouldIce 159

Product: Soft scoop ice cream 10% fat.

Recipe:

	%	%
Palsgaard® MouldIce 159	0.90	0.90
Anhydrous milk fat/vegetable fat	10.00	10.00
Skim milk powder	10.80	11.00
Dextrose	5.00	
Glycerol		2.50
Sugar	10.00	10.00
Glucose syrup, 42DE	4.00	4.00
Water	59.30	61.40

Add colour and flavour as desired

Composition of solids:

	%	%
Fat	10.00	10.00
Sugar	18.00	14.00
Milk-solids-non-fat	10.30	10.50
Palsgaard® MouldIce 159	0.90	0.90
Total solids	38.70	36.90

Relative sweetness	15.8	14.2
Freezing point	-3.1	-3.1

Procedure:

- * Add Palsgaard® MouldIce 159 to the ice cream mix while stirring.
- * Pasteurization: E.g. 80 °C/30 sec.
- * Homogenization:., Kp/ cm², approx:

Anhydrous milk fat	160	160
Vegetable fat	140	140

Identification: ICE CREAM SOFT SCOOP (00590801-EU-E-RS)

Palsgaard A/S – Palsgaardvej 10 – DK-7130 Juelsminde – Denmark – Phone: +45 76 82 76 82 – E-mail: Direct@palsgaard.dk – Fax: +45 76 82 76 83

The product is tested and recommended for use in mentioned application only. The information given is, to the best of our knowledge, reliable. However, no guarantees are given, not even in case of negligence on the part of Palsgaard A/S, and users of our products, are recommended and advised to conduct their own trials to determine whether our products are suitable for the user's specific purposes. In case of delivery of defective products the user is only entitled to order a new delivery. Palsgaard A/S assumes no guarantee against patent infringement, liabilities or risks involved from the use of this product or information given.

- * Cool below 5° C and age for min. 4 hours.

Identification: ICE CREAM SOFT SCOOP (00590801-EU-E-RS)

Palsgaard A/S – Palsgaardvej 10 – DK-7130 Juelsminde – Denmark – Phone: +45 76 82 76 82 – E-mail: Direct@palsgaard.dk – Fax: +45 76 82 76 83
The product is tested and recommended for use in mentioned application only. The information given is, to the best of our knowledge, reliable. However, no guarantees are given, not even in case of negligence on the part of Palsgaard A/S, and users of our products, are recommended and advised to conduct their own trials to determine whether our products are suitable for the user's specific purposes. In case of delivery of defective products the user is only entitled to order a new delivery. Palsgaard A/S assumes no guarantee against patent infringement, liabilities or risks involved from the use of this product or information given.